


NWT 4 Linux & Windows 26 februari 2011, 13:43

Startfreq: 10.100000 MHz; Stopfreq: 10.150000 MHz; Width: 0.050 kHz

Samples: 1001; Interrupt: 0 uS



Kabel 0,25 mm² RKUR

30m deltaloopt hela bandet.

Cursor 1:

10.139250 MHz

SWR : 1.1993

SWR min : 1.18 10.111400

SWR max : 1.21 10.149200

